




## FEATURES




## HOW TO START



1. Press the power button to turn on/off.

2. Tap 'GO' on each page to start.
Otherwise the last sound will just repeat.





3. Firmly press the graphics on the box to hear the audio.

4. Press the language button to switch between Spanish and English.

## BATTERY



Requires 2 AA batteries (not included).





If you hear any sound defects or irregularities, it's time to replace the batteries. Fresh batteries ensure the best performance.

